

TECHNICAL POLYMERS MED RANGE

Chemical resistance



CHEMICAL RESISTANCE OF ARKEMA'S MEDICAL-GRADE SPECIALTY POLYMERS

As healthcare technology continues to advance, the need for high performance medical grade polymers will increase. Arkema, having been a key player in the healthcare market, recognizes the importance of thoroughly understanding the chemical resistance profile of its Medical Grade Polymers. In order to ensure optimal material selection for its customers, Arkema has conducted a chemical resistance study with the top chemical agents commonly used in hospitals and other healthcare settings along with its Medical Grade Polymers.

The chart below demonstrates the qualitative performance of chemical resistance based on surface aspect (the appearance of cracks) and coloration. Environmental stress cracking resistance tests (ESCR) were performed using elliptical Bergen jig, which applies a range of strains to a single sample bar and injected plates immersed into the indicated chemical agent at room temperature (23°C) for 24 hours.

TABLE 1- List of chemical agents

Main category	Chemical composition	CAS numbers	Commercial products (Hospital)
Bleach	Sodium hypochlorite 11-15% diluted at 0.2%	7681-52-9	10% bleach solution
			Clorox Bleach
			Dispatch
			Dispatch™ Hospital cleaner
			Disinfectant with bleach
			Sani-cloth™ Bleach Wipe
			Alcavis Bleach Wipe 1:10
H ₂ O ₂	Hydrogen peroxide (30%) and peracetic acid (38-40%- diluted at 5%)	7722-84-1 and 79-21-0	Accel TB wipes
			Ecolabs oxycide
			Virox
IPA	2-propanol 100%	67-63-0	Isopropyl alcohol (or propan-2-ol or isopropanol)
			70% IPA solution
Phenol	CRESYL (10% hexylene glycol + 1% orthobenzylparachlorophenol + 0.1% O-phenylphenol)	59-50-7 and 90-43-7 and 120-32-1	Wex-cide 128
			Precise
			Sporicidin
			Precise™ Hospital Foam cleaner disinfectant
			Sporicidin™
			Vesphene IIse
QAC (Anti-infective agent)	Benzethonium chloride 98% diluted at 0.3%	121-54-0	Sanicloth HB wipe
			Sanicloth Super
			Sanicloth AF3
			Virex TB
Glycol Ether	2-butoxyethanol 99% diluted at 5%	111-76-2	Cavicide
Detergent	Chlorohexidine digluconate 30% diluted at 1%	18472-51-0	Aniospray 29
			Clinell detergent wipe
			Cidex (2.4% glutaraldehyde)
			Cidex OPA
DMSO	Dimethyl sulfoxide 99%	67-68-5	-

TABLE 2

		Bleach	H ₂ O ₂	IPA	Phenol	QAC	Ether	Detergent	DMSO
Pebax® MED	2533	++	++	++	+	++	++	++	++
	3533	++	++	++	+	++	++	++	++
	4033	+++	+++	+++	+	+++	+++	+++	+++
	4533	+++	+++	+++	+	+++	+++	+++	+++
	5533	+++	+++	+++	+	+++	+++	+++	+++
	6333	+++	+++	+++	+	+++	+++	+++	+++
	7033	+++	+++	+++	+	+++	+++	+++	+++
	7233	+++	+++	+++	+	+++	+++	+++	+++
	7433	+++	+++	+++	++	+++	+++	+++	+++
	MV1074	+++	+++	++	+	+++	+++	+++	+++
Rilsamid® MED	AESNO	+++	+++	+++	+++	+++	+++	+++	+++
	AMNO	+++	+++	+++	+++	+++	+++	+++	+++
Rilsan® MED	BESNO	+++	+++	+++	+	+++	+++	+++	+++
	BMNO	+++	+++	+++	+	+++	+++	+++	+++
	BESVO A	+++	+++	+++	+	+++	+++	+++	+++
Rilsan® Clear MED	G170	+++	+++	+	+	+++	+++	+++	+++
	G850 Rnew	+++	0	0	+	+++	+++	+++	+++
Kynar® MED	720	+++	+++	+++	+	+++	+++	+++	++

QUALITATIVE KEY FOR CHEMICAL RESISTANCE

- +++ Resistant. No or little change in weight or dimensions, no damage
- ++ Limited resistance. Changes in weight or dimensions after longer periods, possibly irreversible changes of properties. We recommend contacting us before use
- + Not resistant. May still sometimes be used under specific conditions (short exposure time, contact droplets)
- 0 Soluble or attacked after brief contact

Environmental stress cracking



Global Manufacturing, Technical Support, and R&D

Europe

 **Innovation Hub** Serquigny, FR

 **Tech Support** Serquigny, FR

 **Plant** Serquigny, FR

Americas

 **Innovation Hub** King of Prussia, PA

 **Tech Support** King of Prussia, PA

 **Plants** Birdsboro, PA - Calvert City, KY

Asia

 **Tech Support** Changshu, CN

 **Tech Support** Kyoto, JP

 **Tech Support** Seoul, KR

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, ARKEMA expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations. Arkema has implemented a Medical Policy regarding the use of Arkema products in Medical Devices applications that are in contact with the body or circulating bodily fluids: (<http://www.arkema.com/en/social-responsibility/responsible-product-management/medical-device-policy/index.html>). Arkema has designated Medical grades to be used for such Medical Device applications. Products that have not been designated as Medical grades are not authorized by Arkema for use in Medical Device applications that are in contact with the body or circulating bodily fluids. In addition, Arkema strictly prohibits the use of any Arkema products in Medical Device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. The Arkema trademarks and the Arkema name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Arkema allows, endorses or permits the use of Arkema products in such medical devices. It is the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade Arkema products, in order to ensure that the final end-use product is safe for its end use; performs or functions as intended; and complies with all applicable legal and regulatory requirements (FDA or other national drug agencies) It is the sole responsibility of the manufacturer of the medical device to conduct all necessary tests and inspections and to evaluate the medical device under actual end-use requirements and to adequately advise and warn purchasers, users, and/or learned intermediaries (such as physicians) of pertinent risks and fulfill any postmarket surveillance obligations. Any decision regarding the appropriateness of a particular Arkema material in a particular medical device should be based on the judgment of the manufacturer, seller, the competent authority, and the treating physician.

Kynar®, Pebax® MED, Rilsamid® MED, Rilsan® MED and Rilsan® Clear MED are registered trademarks of Arkema.

© 2019 Arkema Inc. All rights reserved.

ExtremeMaterials.com

Contact Information

China: +86 21 61476888
Japan: +81 3 5251 9900
Korea: +82 2 37036700
Singapore: +65 64199199
Taiwan: +886 2 27476979
India: +91 22 66137500

Arkema Inc.

900 First Avenue
King of Prussia, PA 19406
USA
Tel.: (+1) 800-596-2750

Headquarters: Arkema France

420, rue d'Estienne d'Orves
92705 Colombes Cedex – France
Tel.: +33 (0)1 49 00 80 80
Fax: +33 (0)1 49 00 83 96
arkema.com

ARKEMA
INNOVATIVE CHEMISTRY